



# TwisTorr 804 FS Turbo Pump Foreline Flange Quick Reference

## Installation instructions


The TwisTorr 804 FS is designed to be operated with a KF25 or a KF40 foreline flange. While the KF40 flange is already installed in the system, the KF25 can be installed with a few simple operations, described below.




Turn the pump upside down and remove screw from its location



Remove foreline flange from the pump



Make sure the o-ring is intact, and then install the provided foreline flange (PN X3511-68001) on the pump



Place the screw back into place (use a 1.5 Nm torque)



Visit the product web page:

<https://www.agilent.com/en/product/vacuum-technologies/turbo-pumps-controllers/turbo-pumps/twistorr-804-fs-turbo-pump>

Please contact Agilent Customer Service for more information:

Americas: [vpl-customer@agilent.com](mailto:vpl-customer@agilent.com)

Europe: [vpt-customer@agilent.com](mailto:vpt-customer@agilent.com)

China: [vpc-customer@agilent.com](mailto:vpc-customer@agilent.com)

Other countries: [vpt-customer@agilent.com](mailto:vpt-customer@agilent.com)

This information is subject to change without notice.